

Manual

NERO-TX^{PRO}

TRUE WIRELESS

Att du som kund ska vara nöjd med dina NERO-TX PRO ser vi på Sound by Sweden som en självklarhet. Skulle du ha några frågor som rör våra produkter når du vår kundsupport på:

support@soundbysweden.se

Vi lämnar ett års garanti på produkten räknat från inköpsdatum (se särskilda villkor gällande förbrukningsdelar på www.soundbysweden.com/se). Garantin gäller i de länder där det finns en, av Sound by Sweden AB, utsedd och godkänd distributör eller representant. Garantin innefattar påvisbara material- eller fabriktionsfel. Denna garanti begränsar inte tvingande lagstiftning eller konsumenträtt. Vid garantiärenden hänvisar vi dig som kund i första hand till inköpsstället.

Garantin gäller ej

- fel orsakade av slitage, olyckor, fall eller annan yttre mekanisk påverkan samt oaktsam hantering
- batterikapacitetsförändring p.g.a. ålder
- modifierad eller "egenreparerad" produkt

1. Ladda dina NERO-TX PRO i laddningsboxen Powermag© tills LED-lampan på hörluren släcks. LED:en lyser vitt under laddningsprocessen.
2. Aktivera Bluetooth® på den sändande enheten (ex. telefonen).
3. Ta ur båda hörlurarna ur laddningsboxen.
De börjar då automatiskt att söka efter en enhet att ansluta till. När hörlurarna söker blinkar dioden vitt och du hör rösten säga "pairing".
4. Anslut hörlurarna genom att välja NERO-TX PRO i listan av tillgängliga Bluetooth-enheter på den sändande enheten.

OBS! Ladda laddningsboxen genom att ansluta den medföljande laddkabeln till USB-C porten. Den större USB-A porten är endast till för utgående ström. Läs mer under rubriken Powermag©.

Komfort & passform

SV

För att optimera komfort och passform är det viktigt att välja rätt storlek på hörlurskuddarna. För små kuddar leder till svag bas och att störande omgivningsljud kan komma in i öronen. För stora kuddar kan medföra att hörlurarna blir obekväma i längden.

Det är viktigt att man får korrekt placering av hörluren i örat. Dels för ljudupplevelsens skull men också för att få en optimal komfort. Börja med att sätta in hörluren med kudden placerad nedåt och vrid sedan luren cirka 90 grader till rätt position enligt skissen nedan.



NERO-TX PRO har 3 lägen för att filtrera bort störande omgivningsljud. För att växla mellan dessa lägen hålls knappen på vänster hörlur (L) intryckt tills du hör:

1. "Noise cancelling on" som filtrerar bort störande omgivningsljud såsom vindbrus, fläktljud, trafik m.m.
2. "Transparency mode" (medhörning) där man filtrerar bort störande omgivningsljud men samtidigt släpper igenom och förstärker samtalsljud, så att du kan kommunicera med din omgivning.
3. "Noise cancelling off" där man filtrerar bort störande omgivningsljud enbart genom passiv brusreducering. För att uppnå bästa effekt i detta läge rekommenderar vi att man använder de medföljande hörlurskuddarna Comfort Foam Tips©.

Samtliga 3 lägen kan aktiveras även om man inte använder hörlurarna för musik eller samtal.

OBS! Använd inte brusreduceringsläget när du befinner dig i omgivningar som kräver din uppmärksamhet, ex. trafikmiljö.

Knappfunktioner på vänster hörlur (L):

- 1 x svara/avsluta samtal.
- 1 x starta/pausa ljud & video.
- 2 x ändra till nästa låt.
- 3 x höja volymen.
- Håll knappen nedtryckt 2 sek. för att växla mellan "Noise cancelling on" "Transparency mode" eller "Noise cancelling off".
- Håll knappen nedtryckt 3 sek. för att starta eller stänga av hörluren.

Knappfunktioner på höger hörlur (R):


- 1 x svara/avsluta samtal.
- 1 x starta/pausa ljud & video.
- 2 x ändra till föregående låt.
- 3 x sänka volymen.
- Håll knappen nedtryckt 2 sek. för att aktivera röstassistenten.
- Håll knappen nedtryckt 3 sek. för att starta eller stänga av hörluren.

Den medföljande förvarings- och laddningsboxen, kallad Powermag©, innehåller ett kraftfullt batteri som kan ladda hörlurarna upp till 16 gånger vilket ger en total speltid på upp till 100 timmar.

Laddningsboxen har också en "power output" funktion via USB-A kontakten (märkt OUT), som innebär att den också fungerar som en reservladdare för exempelvis din mobiltelefon. Reservladdningen sker genom att ansluta en USB-kabel mellan laddningsboxens USB-A kontakt och telefonen (laddningen startar automatiskt). När funktionen aktiveras tänds en vit LED (ovanför USB-A kontakten). **OBS: Ladda enbart produkter märkta med 5 volt input.**

När batterinivån i laddningsboxen börjar bli låg blinkar LED:en vitt. Ladda boxen genom att ansluta den medföljande laddkabeln. LED:en blinkar vitt under laddningsprocessen. När dioden lyser med fast vit sken är boxen fulladdad. **OBS! Det är viktigt att man ansluter laddkabeln till USB-C ingången och inte till den större USB A kontakten. Denna kontakt är endast till för utgående ström.**

För att skydda USB portarna på laddningsboxen rekommenderar vi att man stänger silikonluckan när kontaktarna inte används.



NERO-TX PRO använder röst- och LED-indikation för att visa operationellt läge.

Röstindikatorn:

1. När hörluren startar säger den "Power on".
2. När hörluren letar efter en enhet att ansluta till säger den "Pairing".
3. När hörluren ansluter till en annan enhet säger den "NERO-TX connected".
4. När batteriet når en nivå på 10% varnar hörluren genom att säga "Battery low".
5. När hörluren stängs av säger den "Power off".
6. När brusreduceringsläget aktiveras säger den "Noise cancelling on".
7. När medhörningsläget aktiveras säger den "Transparency mode".
8. När man väljer det passiva brusreduceringsläget säger den "Noise cancelling off".

LED-dioden på hörlurarna:

1. LED blinkar vitt = ingen enhet ansluten.
2. LED blinkar vitt = söker efter enhet.
3. LED blinkar vitt = lågt batteri <10%.
4. LED lyser vitt i laddningsboxen = laddar batteri.
5. LED lyser ej i laddningsbox = batteri fulladdat.

LED-dioden på Powermagen:

1. LED blinkar vitt när boxens batteri laddas.
2. LED blinkar vitt när hörlurarna laddas.
3. LED blinkar vitt när man använder boxen för att ladda annan enhet kopplad via USB-A porten (Power out).
4. LED lyser med fast vitt sken när batteriet i boxen är fulladdat.

Support and warranty

EN

We at Sound by Sweden hope that you will be pleased with your new NERO-TX PRO. If you have any questions concerning our products you can reach our customer support team at:

support@soundbysweden.se

We provide one-year warranty on this product from the date of purchase (see special terms regarding wearing parts at soundbysweden.com). The warranty applies in countries where there is a reseller or representative appointed and approved by Sound by Sweden AB. The warranty covers demonstrable material and manufacturing faults. This warranty does not restrict the rights of the consumer mandated under applicable laws. If you would like to make use of this warranty, then please contact the point of purchase in the first instance.

The warranty does not cover:

- faults caused by wear and tear, accidents, drops, falls or other external mechanical impacts caused by careless handling.
- changes to battery capacity as a result of age.
- unauthorized modifications or repairs performed by the user.

1. Charge your NERO-TX PRO in the charging box Powermag© until the LED light on the earphone turns off. The LED will light up white during the charging process.
2. Activate Bluetooth® on the transmitting device (e.g. smartphone).
3. Take out both earphones from the charging box. They will then begin automatically searching for a device to pair with. When the earphones are searching for a device, the LED will flashes white and you will hear the voice prompt "pairing".
4. Connect the earphones by selecting NERO-TX PRO from the list of available Bluetooth devices on the transmitting device.

NB! Charge the charging box by connecting the supplied charging cable to the USB-C port. The larger USB-A port (marked OUT) port is for outgoing current only. Read more in the section entitled Powermag©.

Comfort and fit

EN

In order to ensure optimal comfort and fit it is important that you choose the right size of earphone tips. Tips that are too small for your ear canal will result in weak bass and may allow ambient noise to disturb the sound experience. Tips which are too big may prove uncomfortable to wear over time.

It is also important to position the earphones correctly in your ears. Earphone positioning affects both your audio experience and wearing comfort. Begin by placing the earphone with the cushion placed downwards and then twist it 90 degrees into the right position as shown below.



Noise cancelling & Transparency EN

NERO-TX PRO has 3 modes to filter out disturbing ambient noise. To switch between these modes, hold down the button on the left earphone (L) until you hear:

1. "Noise cancelling on" where you filter out disturbing ambient noise such as wind, fan noise, traffic etc.
2. "Transparency mode" (listening) where you filter out disturbing ambient noise but at the same time let through and amplify conversation sound, so you can communicate with your surroundings.
3. "Noise cancelling off" where you filter out disturbing ambient noise only by passive noise reduction. To get the best possible effect in this mode, we recommend using the included Comfort Foam Tips®.

All 3 modes can be activated on the earphones even if you do not use them for music or calls.

NB! Do not use noise cancelling in demanding environments attention to sounds around for example in traffic environments.

Buttons functions on the left earphone (L):

- 1 x answer/end a call.
- 1 x start/pause sound and video.
- 2 x skip to the next track.
- 3 x increase the volume.
- Press the button for two seconds to activate "Noise cancelling on", "Transparency mode" or "Noise cancelling off".
- Press the button for three seconds to turn the earphone on or off.

Button functions on the right earphone (R):

- 1 x answer/end a call.
- 1 x start/pause sound and video.
- 2 x go back to the previous track.
- 3 x decrease the volume.
- Press the button for two seconds to activate voice assistance.
- Press the button for three seconds to turn the earphone on or off.

The accompanying storage and charging case, called Powermag©, contains a powerful battery that can recharge the earphones up to 16 times, giving a total play time of up to 100 hours.

The charging case also has a power output function via the USB-A connection (marked OUT), which means that it can also double as a powerbank for other devices such as your smartphone. You can make use of this function by connecting a USB cable to the USB-A port on the charging box and to your smartphone (charging will start automatically). When this function is active a white LED will light up (above the USB-A port).

NB: Only charge products that have a power input of 5 Volts.

When the battery level of the Powermag© becomes low, the LED light will start flashing white. Charge it by connecting the charging cable supplied. The LED will flash white during the charging process. The LED will shine with a solid white light when the Powermag is fully recharged.

NB! It is important that you connect the supplied charging cable to the smaller USB-C input and not to the larger USB-A connection. This connection is only for outgoing current.

To protect the USB ports on the charging box, we recommend that you close the silicone cover whenever the ports are not being used.



NERO-TX PRO uses voice and LED indicators in order to indicate its current operational mode.

Voice indicators:

1. When the earphone starts up you'll hear the voice prompt: "Power on".
2. When the earphone is searching for a device to pair with you'll hear the voice prompt: "Pairing".
3. When the earphone connects to another device you'll hear the voice prompt: "NERO-TX connected".
4. When the battery level reaches less than 10% it will warn the user by saying: "Battery low".
5. When the earphone switches off you'll hear the voice prompt: "Power off".
6. When the noise cancelling mode is being activated you'll hear the voice prompt: "Noise cancelling on".
7. When the transparency mode is being activated you'll hear the voice prompt: "Transparency mode".
8. When the passive noise cancelling mode is being activated you'll hear the voice prompt: "Noise cancelling off".

LED light on the earphones:

1. LED flashes white = no device connected.
2. LED flashes white = searching for device.
3. LED flashes white = battery level is less than 10%.
4. LED shines solid white = battery in earphone is recharged (when earphones are in charging case).

LED light on the charging case:

1. LED flashes white when the charging case is being charged.
2. LED flashes white when the earphones are being charged.
3. LED flashes white when the Powerbank is charging device via USB-A.
4. LED shines solid white when charging case is fully recharged.