

MANUAL



NiTRO-X
WIRELESS

Vi gratulerar dig till köpet av dina nya NiTRO-X!

Våra produkter utvecklas och produceras i enlighet med vårt koncept som vi har valt att kalla "New Generation of Sound". Det innebär att produkten ska ha en tekniskt förankrad och innovativ design samt att samtliga komponenter ska vara tillverkade av högsta möjliga materialkvalitet. Konstruktionen ska vara genomtänkt och optimerad för att ge användaren många år av högsta möjliga lyssningsglädje.

Rekommendationer

Lyssna aldrig på högre ljudvolym än vad som upplevs bekvämt. Du riskerar annars att få bestående skador på din hörsel. Använd aldrig hörlurarna i en miljö där din hörsel krävs för att uppfatta fara, såsom exempelvis i trafiken.

Support & garanti

SV

Support

Att du som kund ska vara nöjd med dina NiTRO-X ser vi på Sound by Sweden som en självklarhet. Skulle du ha några frågor som rör våra produkter når du vår kundsupport på: support@soundbysweden.se

Garanti


Vi lämnar ett års garanti på den här produkten räknat från inköpsdatum (se särskilda villkor gällande förbrukningsdelar på soundbysweden.com). Garantin gäller i de länder där det finns en, av Sound by Sweden AB, utsedd och godkänd distributör. Garantin omfattar påvisbara material- eller fabrikationsfel. Denna garanti begränsar inte tvingande lagstiftning eller konsumenträtt.

1. Ladda dina NiTRO-X tills dess att LED-dioden på den vänstra hörlurskåpan släcks. Dioden lyser rött under själva laddningsprocessen.
2. Aktivera Bluetooth® på den sändande enheten (ex. telefonen).
3. Håll on/off knappen intryckt 5 sekunder att aktivera hörlurens parningsfunktion. Du hör rösten säga "Pairing".
4. Anslut genom att välja "NiTRO-X OE" i listan av tillgängliga Bluetooth® enheter på sändande enheten.
5. Du hör rösten säga "NiTRO-X connected" när enheterna är parade med varandra.
6. Klart att börja använda hörlurarna.

Knapparnas funktioner

SV

1. Aktivera/avaktivera brusreducering (LED:en på knappen lyser blått när brusreduceringsfunktionen är aktiverad)
2. Ingång för 3.5mm ljudkabel. Används vid lyssning med aux-kabel då man inte vill ha trådlös ljudöverföring (vid lyssning med kabel är mikrofonen för samtal ej aktiverad)
3. Multifunktionsknapp:
 - På/Av genom att hålla knappen nedtryckt i 3 sekunder.
 - Svara/avsluta samtal med ett knapptryck.
 - Dubbelklicka för att aktivera röstassistenten (Siri/Google)
 - Starta/pausa musik genom ett knapptryck.
4. - Höj volymen genom att trycka på knappen.
 - Ändra till nästa låt genom att hålla knappen nedtryckt.
5. - Sänk volymen genom att trycka på knappen.
 - Ändra till tidigare låt genom att hålla knappen nedtryckt.
6. Laddningsport för Micro USB-kabel (laddkabel medföljer).



NiTRO-X använder röstindikator för att informera om operationellt läge.

1. När hörluren startas säger rösten "Power on"
2. När hörluren söker efter enhet att ansluta till säger rösten "Pairing"
3. När hörluren ansluter till en annan enhet säger rösten "NiTRO-X connected"
4. När hörluren tappat kontakt med ansluten enhet säger rösten "Disconnected"
5. När batteriet når en batterinivå på 10% säger rösten "Battery low"
6. När hörluren stängs av säger rösten "Power off"

Introduction

ENG

Congratulations to your new NiTRO-X headphone!

Sound by Sweden products are developed and produced according to our "New Generation of Sound" concept, meaning that the design should endorse proven technical properties, be innovative as well as consist of highest material standards. The concept should always result in a product offering the highest level of music listening pleasure.

Recommendation

Never listen to volume above comfortable levels. If you do, you might damage your hearing irreversibly. Never use headphones when your attention to sounds/warnings is critical, e.g. in traffic.

Support & Warranty

ENG

Support

We aim at nothing less than 100% satisfaction from your new NiTRO-X. Should you have any questions regarding your headphone, please contact our support: support@soundbysweden.se

Warranty

We provide a one-year warranty on this product, starting from the date of purchase (see special conditions applicable to consumable parts at soundbysweden.com). The warranty is valid in any country where there is one, of Sound by Sweden AB, appointed and authorized distributor or reseller. Sound by Sweden AB warrants this product against defects in materials or workmanship. The warranty does not limit local warranty or consumer rights legislations.

Quick start


ENG

1. Start charging your NiTRO-X until the LED on the left headphone house stop shine. The LED shines red during the charging process.
2. Activate Bluetooth® on your transmitting device.
3. Press the power button on the headphone for 5 seconds to activate paring mode.
4. Choose NiTRO-X OE in your transmitting device, under Bluetooth® menu.
5. The voice prompt "NiTRO-X connected" will indicate when the pairing is completed.
6. The headphones are now ready to use.

Functions

ENG

1. Enable/Disable noise cancelling (LED on the button shines blue when noise reduction function is enabled)
2. Input for 3.5mm audio cable. Used when listening with aux-cable instead of wireless audio transmission (when listening with cable, the mic for calls is not activated).
3. Multifunction key:
 - On/Off by holding down the button for 3 seconds.
 - Answer/end calls by clicking the button.
 - Play/pause music by clicking the button.
 - Activate voice assistant by double-clicking (Siri/Google).
4. - Increase the volume by clicking the button.
 - Hold button to skip forward
5. - Lower the volume by clicking the button.
 - Hold button to skip back.
6. Charging port for Micro USB cable (included in package).



NiTRO-X uses voice indicator to indicate operating mode.

1. When starting the headphone you'll hear the voice prompt "Power on"
2. When the headphone searches for another device to connect to, you'll hear the voice prompt "Pairing"
3. When the headphone connects to another device you'll hear the voice prompt "NiTRO-X connected"
4. When the headphone loses contact with a connected device, you'll hear the voice prompt "Disconnected"
5. When the battery reaches a level of 10% you'll hear the voice prompt "Battery low"
6. When you turn off your NiTRO-X you'll hear the voice prompt "Power off"