

Manual

NERO-TX

Att du som kund ska vara nöjd med dina NERO-TX ser vi på Sound by Sweden som en självklarhet. Skulle du ha några frågor som rör våra produkter när du vår kundsupport på:

support@soundbysweden.se

Vi lämnar ett års garanti på den här produkten räknat från inköpsdatum (se särskilda villkor gällande förbrukningsdelar på soundbysweden.se). Garantin gäller i de länder där det finns en, av Sound by Sweden AB, utsedd och godkänd distributör eller representant. Garantin innefattar påvisbara material- eller fabriktionsfel. Denna garanti begränsar inte tvingande lagstiftning eller konsumenträtt. Vid garantiärenden hänvisar vi dig i första hand till inköpsstället.

Garantin gäller ej

- fel orsakade av slitage, olyckor, fall eller annan yttre mekanisk påverkan och oaktsam hantering
- batterikapacitetsförändring p.g.a. ålder
- modifierad eller "egenreparerad" produkt

1. Ladda dina NERO-TX i laddningsboxen (Powermag©) tills LED-lampan på hörluren släcks. LED:en lyser vitt under laddnings-processen.
2. Aktivera Bluetooth® på den sändande enheten (ex. telefonen).
3. Ta ur den vänstra hörluren, markerad med "L", ur laddningsboxen. Den börjar då automatiskt att söka efter en enhet att parkoppla med. När hörluren söker lyser dioden vitt och du hör rösten säga "pairing".
4. Anslut hörluren genom att välja NERO-TX i listan av tillgängliga Bluetooth-enheter på den sändande enheten.
5. Ta ur den högra hörluren, markerad med "R", ur laddningsboxen. Den ansluter då automatiskt till vänster hörlur. Du hör rösten säga "connected" när hörlurarna är kopplade till varandra. Hörlurarna är nu färdiga att använda.

OBS! Ladda laddningsboxen genom att ansluta laddkabeln till Micro USB porten. Den större USB-A porten är endast till för utgående ström. Läs mer under rubriken Powermag©.

Komfort & passform

SV

För att optimera komfort och passform är det viktigt att välja rätt storlek på hörlurskuddarna. För små kuddar leder till svag bas och att störande omgivningsljud kan komma in i öronen. För stora kuddar kan medföra att de blir obekväma i längden.

Det är viktigt att man får korrekt placering av hörluren i örat. Dels för ljudupplevelsens skull men också för att få en optimal komfort. Börja med att sätta in hörluren med kudden placerad nedåt och vrid sedan luren cirka 45 grader till rätt position enligt skissen nedan.



Knappfunktioner på vänster hörlur (L):

- 1 x svara/avsluta samtal
- 1 x starta/pausa ljud & video
- 2 x ändra till nästa låt.
- 3 x höja volymen.
- Håll knappen nedtryckt 2 sek. för att aktivera röstassistenten.
- Håll knappen nedtryckt 3 sek. för att starta eller stänga av hörluren.

Knappfunktioner på höger hörlur (R):

- 1 x svara/avsluta samtal
- 1 x starta/pausa ljud & video
- 2 x ändra till föregående låt.
- 3 x sänka volymen.
- Håll knappen nedtryckt 2 sek. för att aktivera röstassistenten.
- Håll knappen nedtryckt 3 sek. för att starta eller stänga av hörluren.

Den medföljande förvarings- och laddningsboxen, kallad Powermag©, innehåller ett kraftfullt batteri som kan ladda hörlurarna upp till 16 gånger vilket ger en total speltid på upp till 80 timmar.

Laddningsboxen har också en "power output" funktion via USB A kontakten, som innebär att den också fungerar som en reservladdare för exempelvis din mobiltelefon. Reservladdningen sker genom att ansluta en USB-kabel mellan laddningsboxens USB A kontakt och telefonen (laddningen startar automatiskt). När funktionen aktiveras tänds en vit LED (ovanför USB A kontakten). **OBS: Ladda aldrig produkter som inte har 5 volt "input" då det kan förstöra utrustningen som ska laddas.**

När batterinivån i laddningsboxen börjar bli låg blinkar LED:en rött. Ladda boxen genom att ansluta den medföljande laddkabeln. LED:en blinkar rött under laddningsprocessen. När dioden lyser med fast rött sken är den fulladdad. **OBS! Det är viktigt att man ansluter laddkabeln till den mindre Micro USB ingången och inte till den större USB A kontakten. Denna kontakt är endast för utgående ström.**

För att skydda USB portarna på laddningsboxen rekommenderar vi att man stänger silikonluckan när kontaktarna inte används.



NERO-TX använder röst- och LED-indikation för att visa operationellt läge:

Röstindikatorn:

1. När hörluren startar säger den "Power on"
2. När hörluren letar efter en enhet att para med säger den "Pairing"
3. När hörluren ansluter till en annan enhet säger den "NERO-TX connected"
4. När batteriet når en nivå på 10% varnar hörluren genom att säga "Battery low"
5. När hörluren stängs av säger den "Power off"

LED-dioden på hörlurarna:

1. LED blinkar vit = ingen enhet ansluten
2. LED blinkar vit x 2 = ansluten till enhet
3. LED lyser vit = söker efter enhet
4. LED blinkar röd = lågt batteri <10%
5. LED lyser vit i laddningsboxen = laddar batteri
6. LED lyser ej i laddningsbox = batteri fulladdat

Support and warranty

EN

Here at Sound by Sweden we naturally hope that you will be pleased with your NERO-TX. If you have any questions concerning our products then you can reach our customer support team at:

support@soundbysweden.se

We offer a one-year warranty on this product calculated from the date of purchase (see special terms regarding wearing parts at soundbysweden.se). The warranty applies in countries where there is a reseller or representative appointed and approved by Sound by Sweden AB. The warranty covers demonstrable material and manufacturing faults. This warranty does not restrict the rights of the consumer mandated under applicable laws. If you would like to make use of this warranty, then please contact the point of purchase in the first instance.

The warranty does not cover:

- faults caused by wear and tear, accidents, drops, falls or other external mechanical impacts caused by careless handling
- changes to battery capacity as a result of age
- unauthorised modifications or repairs performed by the user

Quick start

EN

1. Charge your NERO-TX in the charging box (Powermag©) until the LED light on the earphone turns off. The LED will light up white during the charging process.
2. Activate Bluetooth® on the transmitting device (e.g. smartphone).
3. Take out the left earphone (marked with an "L") from the charging box. It will then begin automatically searching for a device to pair with. When the earphone is searching for a device, the LED will light up white and you will hear a voice that says: "pairing".
4. Connect the earphone by selecting NERO-TX from the list of available Bluetooth devices on the transmitting device.
5. Take out the right earphone (marked with an "R") from the charging box. The earphone will then connect automatically to the left earphone. You will hear a voice that says "connected" once the earphones have successfully connected to one another. The earphones are now ready to use.

NOTE! Charge the charging box by connecting the charging cable to the Micro USB port. The larger USB-A port is for outgoing current only. Read more in the section entitled Powermag©.

Comfort and fit

EN

In order to ensure optimal comfort and fit it is important that you choose the right size of earphone tips. The tips that are too small will result in weak base and may allow disturbing ambient noise to reach your ears. Tips which are too big may prove uncomfortable to wear over time.

It is also important to position the earphones correctly in your ears. Earphone position affects both your audio experience and also your comfort. Begin by placing the earphone with the cushion placed downwards and then twist it 45 degrees into the right position as shown below.



Button functions

EN

Buttons functions on the left earphone (L):

- 1 x answer/end a call
- 1 x start/pause sound and video
- 2 x skip to the next track
- 3 x increase the volume
- Hold in the button for two seconds to activate voice assistance.
- Hold in the button for three seconds to turn the earphone on or off.

Button functions on the right earphone (R):

- 1 x answer/end a call
- 1 x start/pause sound and video
- 2 x go back to the previous track
- 3 x decrease the volume
- Hold in the button for two seconds to activate voice assistance.
- Hold in the button for three seconds to turn the earphone on or off

The accompanying storage and charging box, called Powermag©, contains a powerful battery that can charge the earphones up to 16 times, giving a total play time of up to 80 hours.

The charging box also has a power output function via a USB-A connection, which means that it can also double as a reserve power pack for other devices such as your smartphone. You can make use of this function by connecting a USB cable to the USB-A port on the charging box and to your smart phone (charging will start automatically). When this function is active a white LED will light up (above the USB-A port). **NB: Never charge products which do not have a five-volt input as this can cause damage to the device being charged.**

When the battery level of the charging box becomes low, the LED light will start flashing red. Charge the box by connecting the charging cable supplied. The LED will flash red during the charging process. When the light turns to a solid red this means that the charging box is now fully charged.

NB! It is important that you connect the charging cable to the smaller USB input and not to the larger USB-A connection. This connection is only for outgoing current.

In order to protect the USB ports on the charging box we recommend that you close over the silicon cover whenever the ports are not being used.



NERO-TX uses voice and LED indicators in order to indicate its current operational mode:

Voice indicators:

1. When the earphone starts up it will say:
"power on"
2. When the earphone is searching for a device to pair with it will say:
"pairing"
3. When the earphone connects to another device it will say:
"NERO-TX connected"
4. When the battery reaches less than 10% it will warn the user by saying:
"battery low"
5. When the earphone switches off it will say:
"power off"

LED light on the earphones:

1. LED flashes white = no device connected
2. LED flashes white x2 = connected to device
3. LED is a solid white = searching for device
4. LED flashes red = battery level is less than 10%
5. LED on the charging box is a solid white = battery charging
6. LED on the charging box is off = battery is fully charged